

INSTRUCTIONS FOR H3-45 LED CONVERSION KIT

PART NUMBER CTC-4000KIT

KIT INCLUDES

17 LED LIGHT ASSEMBLIES (9 RED, 4 AMBER AND 4 CLEAR)
17 RUBBER GROMMETS
17 90 DEGREE PIGTAILS
1 PANEL SET (L/H PANEL, R/H PANEL AND CYCLOPS LIGHT PANEL.
1 TUBE OF ADHESIVE (SIKA 252)

INSTALLATION INSTRUCTIONS

1. Read all instructions before starting retrofit.
2. Turn off batteries to coach.
3. Remove all original equipment light assemblies.
4. Set light assemblies aside.
5. Remove the panel set; hold the left and right panels one at a time. Trace the holes from the panel set to coach engine door. Ensure to leave yourself at least 5/16 of an inch around all edges to hold the grommet.
6. Cut out along your traced outline on the engine door. Discard pieces.
7. Complete step 6 for all three panels (left, right and center)
8. The center piece may need to be trimmed a little to fit properly onto coach.
9. Clean both engine door and all three panels with denatured alcohol or equivalent.
10. Apply a thin layer of adhesive (included in kit) to panel and adhere to coach.
11. To ensure the panel is centered you may want to place a light and grommet in opposing holes of panel.
12. Complete step 11 for all three panels.
13. Allow for adhesive to cure no less than 8 hours before use of coach.
14. Begin installing pigtails. Black = minor, Red = major White = ground.
15. After all pigtails are wired in, install all lights
16. Turn batteries back to the on position and test all lights.
17. Conversion is complete.

INSTRUCTIONS FOR H3-45 LED CONVERSION KIT

